1/10th 4WD Nitro Power R/C Sport Rally Racing

Specifications:

LENGTH	WIDTH	HEIGHT	WHEEL BASE	DRIVE SYSTEM	WHEEL DISTANCE	DIAMETER OF WHEEL	WIDTH OF WHEEL	GEAR RATIO
475mm	252mm	165mm	275mm	4WD Shaft Drive	220mm	86mm	32mm	1:5.84(L) 1:8.58(H)

Spare Part

06056-Chassis	06051-Front Upper Arm(L/R)	06052-Front Lower Arm	06053-Rear Lower Arm	06054-Rear Anti-Squat Plate
06055-Front Upper Arm Holder	06062-Shock Absorber	06058-Front Shock Tower	06059-Rear Shock Tower	06043-Steering Hub (Left/Right)
06044-Rear Wheel Hub Carrier (Left/Right)	06045-Front Gear Box Housing	06046-Rear Gear Box Housing	06063-Front Gear Box Complete	06064-Rear Gear Box Complete
02173-Suspension Arm Pad	02074-Steering Ackerman Joint	06071-Steering Assembly B	02025-Steering A	02110-Radio Tray
02046-Radio Tray Post A	02047-Radio Tray Post B	02006-Front/Rear Throttle Mount	06034-Centre Diff. Complete	02009-Front Bumper Upper Cover
20131-Front Body Post	20132-Front Bumper	20133-Front Bumper Foam	20134-Rear Post Mount+Body Post	06101-Wheel Rim

Spare Part

30710-Tyre+Insert Sponge	30712- Wheel Complete	02168-Wheel Axle	02100-Wheel Hex.	08027-Pin 2*10mm
02070-Battery Compartment	02111-Battery Cover	02072-Servo Arm	Sp3003-Steering/ Throttle Servo 3kg Sp3004-Steering/ Throttle Servo 3kg (Optional)	06016-Front/Rear Link &Steering Servo Link
02024-Diff.Main Gear Complete	02029-Crown Gear (38T)	02030-Drive Gear	02066-Diff.Pinions+ Pin	06232-Spur Gear(47T)
06033-Spur Gear(42T) 2*8	02068-Engine Flywheel	02023-Clutch Bell (Double Gear)	02032-Universal Joint Cup C	02034-Universal Joint Cup A/Grub Hex. Screw 4*4
02016-Universal Joint Cup B/Set Screws4*4	02003-Rear Dogbone /Centre Dog bone Hole Track:55mm Total Length:61mm	06006-Front Dogbone 76mm	06061-Dogbone(F/R) 84mm	02036-3*44mm Front Suspension Arm Pin A
02063-3*54mm Rear Suspension Arm Pin A	06060-Front Lower Suspension Arm Round Pin B Φ3*39mm	02004-Fuel Tank	02058-Fuel Tube	02172-Exhaust Pipe Tubing
02026-Exhaust Pipe	02028-Air Filter W/Sponge	02031-Exhaust Manifold	02048-Clutch Shoe(w/ Spring) 02048(M) 02048(F)	02049-Engine Holder W/Column Head Screws M3*10

Upgradable Optionals

122203-Aluminum Radio Tray Mount/Post+Cap Head Machine Screw3*10 *4P+3*8*4P+Flat Head Machine Screw3*10* 4P	122205-Aluminum Engine Mount	122206-Aluminum Lightweight Flywheel	102009-Aluminum Exhaust Pipe	122042-Aluminum Wheel Hex Mount
122048-Aluminum Locknut M3	122049-Aluminum Locknut M4	122225-AL. Centre Diff. Mount+Posts/Flat Head Machine Screw 3*10* 8P	122227-Aluminum Suspension Arm Reinforcement Brack	122234-Aluminum Rear Anti-Squat Plate/Flat Head Machine Screw 3* 10* 2P
122240-Aluminum Ackerman Plate	122257-Alum.Steering Servo Saver Complete	122259-Aluminum Fuel Tank Cover+Cap Head Machine Screw 2P	122273-Aluminum Clutch Shoe	122275-AL. Gear Box/Flat Head Machine Screw3*10 *4P/Cap Head Machine Screw 3*15*2P+3*10*2P/ Round Head Machine Screw 3*12*2P
166004-Aluminum Shock Absorber	166015-Universal Drive Joint	166611-Aluminum Steering Hubs(L/R)+ Ball Head Nut 4P	166612-Aluminum Rear Hub Carrier (L/R) +Ball Head Nut 4P	166617-Aluminum Front/Rear & Servo Link 2P/Flat Head Machine Screw3*14* 4P/Nut M3*4P
166618-Aluminum Front Upper Arm /M5 Ball Head Screw 2P	166619-AL. Front Lower Arm/Cap Head Machine Screw3*14* 2P/Grub Screw4*6* 2P/ M5 Ball Head Screw 2P	166621-AL.Rear Lower Arm/Cap Head Machine Screw3*14* 2P/Grub Screw4*6* 2P/M5 Ball Head Screw 4P	166622-Aluminum Front Shock Tower	166623-Aluminum Rear Shock Tower
188865-Aluminum Fuel Tank/Radio Tray	106673-Alum.Front Wheel Rim	166664-Aluminum Battery Cover	80237-Anodized Aluminum Servo Arms	188831-Aluminum Front Upper Arm Mount+Cap Head Machine Screw 4P
02031A-Polished Aluminum Manifold+ Pad	02156-Aluminum Fuel Filter	04104- Alum.Capped Air Filter Cover Optional Use		













Spare Part

02011-Handle	02174-Throttle/Brake Assembly	02059-Exhaust Pipe Holder w/Cap Screw& Nut	02044- Disc Brake	02039-Differential Box+Seals+Washers
02043-Brake Cam	02045-Two Way Drive Clutch	02054-Centre Gear Shaft	02067-Hex.Bearing	16602-Switch
02065-Flywheel Pilot Post	02155-Chargeable Battery Pack (6V 1100mA)	02171-Sway Arm Adjuster	02153-Ball Head Nut	02152-M5 Ball Head Screw
02038-Ball Head Screw	06023-Shock Ball Stud B	06007-Shock Ball Head C	02164-Ball Head Cap	02101- Steering Bushing
02102-Nylon Nut M3	02055-Nylon Nut M4	02037-E-Clip (Φ7Φ4Φ2.5Φ2.3)	02057-Antenna Pipe	02053-Body Clip
02103-Zip Tie	03027-Charger/Battery Wire Connector	02501-Washer 8*5.2*0.5	02078-O-Ring	02079-Oil Bearing Φ15*Φ10*4
02080-Oil Bearing Φ5*Φ10*4	02138-Ball Bearing Φ15*Φ10*4	02139-Ball Bearing Φ10*Φ5*4	02098-M3*4 Grub Hex. Screw	02099- Grub Hex. Screw M4*4
61018- Grub Hex. Screw M4*10	02181-Cap Head Self-Tapping Screw 3*15 10P	02083-Cap Head Self-Tapping Screw3*12 6P	02081-Cap Head Self-Tapping Screw 3*8 6P	02082-Cap Head Self-Tapping Screw 3*10 10P

Spare Part

02084-TT3*20 BH Screw 4P	02176-3*12 Cap Head Machine Screw 4P	02097-3*14 Cap Head Machine Screw 6P	02096-3*10 Cap Head Machine Screw 6P	18243-3*8 Cap Head Machine Screw 10P
02085-Round Head Self-Tapping Screw 2*8 8P	02086-Round Head Self-Tapping Screw 2*10 10P	81220-14-Round Head Self-Tapping Screw 3*12 8P	01083-Round Head Machine Screw 3*11 6P	81220-5-Countersunk Cross Head Machine Screw 3*14 4P
02087-Countersunk Cross Head Self-Tapping Screw3*10 15P	02088-Countersunk Cross Head Self-Tapping Screw3*14 13P	02090-TPE3*25FH Screw 4P	02092-ISO 3*10 Screw 8P	02094-M3*30 Column Head Hex. Screw 4P
02093-M3*10 Column Head Hex. Screw 10P	02095-M3*8 Column Head Hex. Screw 4P	08024- Discal Screw M3*11 8P	02060-Engine 16CXP/18CXP Optional	02200-New Engine 18CXP/20CXP Optional
11016-Pull Starter For 02200 Only				

Optionals

80310-Transmitter 2.4G 28464-Receiver 2.4GHZ	80311-Transmitter 2.4G 28463-Receiver 2.4GHZ	80226G-Transmitter 3-Channel 2.4G 28462-Receiver 2.4GHZ
80309-Transmitter 2.4G 28462-Receiver 2.4GHZ	80308-Transmitter 2.4G 28462-Receiver 2.4GHZ	



Sport Rally Racing Exploded View

1770927